



January 1, 2023
Lit. No. 27097, Rev. 03

MECHANIC'S GUIDE



SNOWPLOWS

Featuring the
**FloStat[®] Hydraulic System &
Isolation Module Light System**

⚠ CAUTION

Read this manual before servicing the snowplow.

TABLE OF CONTENTS

INTRODUCTION	5	THEORY OF OPERATION	18
Recommended Tools	5	Snowplow Headlamps	18
Available Service Items	5	Snowplow Park/Turn Lamps	18
SAFETY	6	Snowplow Hydraulics	18
Safety Definitions	6	HYDRAULIC AND ELECTRICAL SCHEMATICS	19
Warning/Caution and Instruction Labels	6	Legend – Electrical & Hydraulic Symbols	19
Safety Precautions	7	Electrical Schematic – 9-Pin Harness (Typical)	20
Hydraulic Safety	7	Electrical Schematic – 12-Pin Harness (Typical)	21
Fuses	7	Hydraulic Schematic	22
Personal Safety	7	Raise – Electrical	23
Fire and Explosion	8	Raise – Hydraulic	24
Cell Phones	8	Lower – Electrical	25
Ventilation	8	Lower – Hydraulic	26
Battery Safety	8	Angle Right – Electrical	27
Noise	8	Angle Right – Hydraulic	28
Vibration	8	Angle Left – Electrical	29
Torque Chart	8	Angle Left – Hydraulic	30
HYDRAULIC SYSTEM	9	Hold In Raise Position – Hydraulic	31
FloStat® Hydraulic System Specifications	9	Striking An Object While Plowing	32
Hydraulic Hose Routing and Fitting Installation	10	Headlamps – Plow Not Connected – 9-Pin (Typical)	34
Hydraulic Unit Parts Diagram	11	Headlamps – Plow Not Connected – 12-Pin (Typical)	35
Hydraulic Unit Valve Identification and Location	12	High Beam Headlamps – Plow Connected – 9-Pin (Typical)	36
Relief Valve Identification and Location	13	High Beam Headlamps – Plow Connected – 12-Pin (Typical)	37
Pilot-Operated (Poppet-Type) Check Valve		Low Beam Headlamps – Plow Connected – 9-Pin (Typical)	38
Identification and Location	14	Low Beam Headlamps – Plow Connected – 12-Pin (Typical)	39
Vehicle Harness and Vehicle Cable Diagram	15		
OPERATING THE SNOWPLOW	16		
Joystick Control	16		
Hand-Held Control	17		

TROUBLESHOOTING GUIDE	40
Introduction	40
General Diagnostic Table	43
Hydraulic Rams–Inspection and Repair	45
Motor Test	47
Motor Relay Test	49
Vehicle Harness Test – Motor Relay	50
Control Test	51
Pump Pressure Test	53
Cartridge Coil Activation Test	55
Vehicle Harness Test – Cartridge Coils	56
Hydraulic System Test	57
Crossover Relief Valve Inspection and Adjustment	58
Pilot-Operated (Poppet Style) Check Valve Test and Inspection	59
Individual Solenoid Coil Test	60
Solenoid Cartridge Valve Inspection	60
Headlamp Test Diagram – 9-Pin Harness	61
Vehicle Headlamp Test – 9-Pin Harness	62
Plow Headlamp Test – 9-Pin Harness	63
Park/Turn Lamp Test – 9-Pin or 12-Pin Harness	64
Optional Park/Turn Relay Kit Test	65
Optional Park/Turn Relay Kit Schematics	66
Vehicle Headlamp Test – 12-Pin Harness – 3-Relay System Only	67
Plow Headlamp Test – 12-Pin Harness – 3-Relay System Only	69
Headlamp Test Diagram – 12-Pin Harness – 3-Relay System Only ...	71

INTRODUCTION

This guide has been prepared to assist the trained mechanic in the service of WESTERN® snowplows. It also provides safety information and recommendations. We urge all mechanics to read this manual carefully before attempting to service the WESTERN snowplow equipment covered by this guide.

Service of your WESTERN snowplow equipment is best performed by your local Western Products outlet. They know your snowplow best and are interested in your complete satisfaction.

RECOMMENDED TOOLS

Tools required for servicing the electrical and hydraulic systems:

- Long/Slender Needle Nose Pliers
- Flat Screwdriver
- Sockets and Combination Wrenches:
3/8" thru 7/8", 1-1/16", 1-1/8", 2-3/16"
- 2-3/16" open end wrench
- Deep Socket: 7/8"
- 1/4" Socket or Nut Driver
- 12V Test Light
- Torque Wrench (in-lb)
- Allen Wrench Set
- 3000 psi Pressure Gauge w/Adapter Fittings
- Flashlight
- Pick Set
- Hammer
- Digital Volt/Ohm Meter
- Pencil Magnet

AVAILABLE SERVICE ITEMS

Available from your WESTERN outlet:

- UniMount®/UltraMount® Electrical Tester
- Pressure Test Kit

SAFETY

SAFETY DEFINITIONS

⚠️ WARNING

Indicates a potentially hazardous situation that, if not avoided, could result in death or serious personal injury.

⚠️ CAUTION

Indicates a potentially hazardous situation that, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

NOTE: Indicates a situation or action that can lead to damage to your snowplow and vehicle or other property. Other useful information can also be described.

WARNING/CAUTION AND INSTRUCTION LABELS

Become familiar with and inform users about the warning and instruction labels on the back of the blade.

NOTE: If labels are missing or cannot be read, see your sales outlet.

Warning/Caution Label


⚠️ WARNING	
	Blade could drop unexpectedly, crushing or trapping limbs. Lower blade when vehicle is parked.
	Overloading could negatively affect vehicle handling. To avoid serious injury or death, do not exceed GVWR or GAWR including blade and ballast.
⚠️ CAUTION	
	Read Owner's Manual before operating or servicing snowplow.
	Transport speed should not exceed 45 mph (72 km/h). Further reduce speed under adverse travel conditions.
	Plowing speed should not exceed 10 mph (16 km/h).
	See your sales outlet/website for specific vehicle application recommendations.

Instruction Label

MOUNTING PLOW (ON) Read Owner's Manual for complete instructions.


STEP 1

After seating plow horns in receiver brackets, pull Handle up. Shoe will lift off the ground.




STEP 2

Pull and hold Lock Pin out; then rotate Handle UP and release Lock Pin. It must lock into UPPER hole. Stand Hook must grip Receiver Pin.




STEP 3

Plug in electrical connections. Repeat Steps 1 and 2 on other side of snowplow.




STEP 3

Push top of Shoe DOWN. Shoe will be on the ground. Repeat Steps 2 and 3 on other side of snowplow. Back vehicle away.




STEP 2

Pull and hold Lock Pin out; then rotate Handle DOWN and release Lock Pin. It must lock into LOWER hole.




STEP 1

After lowering blade and turning control OFF, disconnect electrical connections.



REMOVING PLOW (OFF) Read Owner's Manual for complete instructions.

US patents 6,941,685; 7,134,227; 7,400,058; 7,430,821; 7,737,576; 9,200,418; 9,822,563; 10,761,056; CAN patents 2,354,257; 2,358,145; 2,358,354; 2,466,195; 2,639,052; 2,843,990; and other patents pending. 67796-12



SAFETY

SAFETY

SAFETY PRECAUTIONS

Improper installation and operation could cause personal injury, and/or equipment and property damage. Read and understand labels and the Owner's Manual before installing, operating, or making adjustments.

⚠ WARNING

Lower the blade when the vehicle is parked. Temperature changes could change hydraulic pressure, causing the blade to drop unexpectedly or damaging hydraulic components. Failure to do this could result in serious personal injury.

⚠ WARNING

The driver shall keep bystanders clear of the blade when it is being raised, lowered, or angled. Do not stand between vehicle and blade or within 8 feet of a moving blade. A moving or falling blade could cause personal injury.

⚠ WARNING

Keep hands and feet clear of the blade and A-frame when mounting or removing the snowplow. Moving or falling assemblies could cause personal injury.

⚠ WARNING

Do not exceed GVWR or GAWR including blade and ballast. The rating label is found on driver-side vehicle door cornerpost.

⚠ WARNING

To prevent accidental movement of the blade, always turn the control OFF whenever the snowplow is not in use. The power indicator light will turn OFF.

⚠ WARNING

Remove blade assembly before placing vehicle on hoist.

⚠ CAUTION

Refer to the current Selection List for minimum vehicle recommendations and ballast requirements.

HYDRAULIC SAFETY

⚠ WARNING

Hydraulic fluid under pressure can cause skin injection injury. If you are injured by hydraulic fluid, get medical attention immediately.

- Always inspect hydraulic components and hoses before using. Replace any damaged or worn parts immediately.
- If you suspect a hose leak, DO NOT use your hand to locate it. Use a piece of cardboard or wood.

FUSES

The electrical and hydraulic systems contain several automotive-style fuses. If a problem should occur and fuse replacement is necessary, the replacement fuse must be of the same type and amperage rating as the original. Installing a fuse with a higher rating can damage the system and could start a fire. Fuse Replacement, including fuse ratings and locations, is located in the Maintenance section of the Owner's Manual.

PERSONAL SAFETY

- Remove ignition key and put the vehicle in PARK or in gear to prevent others from starting the vehicle during installation or service.
- Wear only snug-fitting clothing while working on your vehicle or snowplow.
- Do not wear jewelry or a necktie, and secure long hair.
- Wear safety goggles to protect your eyes from battery acid, gasoline, dirt, and dust.
- Avoid touching hot surfaces such as the engine, radiator, hoses, and exhaust pipes.
- Always have a fire extinguisher rated BC handy, for flammable liquids and electrical fires.

SAFETY

SAFETY

FIRE AND EXPLOSION

⚠ WARNING

Gasoline is highly flammable and gasoline vapor is explosive. Never smoke while working on vehicle. Keep all open flames away from gasoline tank and lines. Wipe up any spilled gasoline immediately.

Be careful when using gasoline. Do not use gasoline to clean parts. Store only in approved containers away from sources of heat or flame.

CELL PHONES

A driver's first responsibility is the safe operation of the vehicle. The most important thing you can do to prevent a crash is to avoid distractions and pay attention to the road. Wait until it is safe to operate mobile communication equipment such as cell phones, text messaging devices, pagers, or two-way radios.

VENTILATION

⚠ WARNING

Vehicle exhaust contains lethal fumes. Breathing these fumes, even in low concentrations, can cause death. Never operate a vehicle in an enclosed area without venting exhaust to the outside.

BATTERY SAFETY

⚠ CAUTION

Batteries normally produce explosive gases, which can cause personal injury. Therefore, do not allow flames, sparks, or lit tobacco to come near the battery. When charging or working near a battery, always cover your face and protect your eyes, and also provide ventilation.

- Batteries contain sulfuric acid, which burns skin, eyes, and clothing.
- Disconnect the battery before removing or replacing any electrical components.

NOISE

Airborne noise emission during use is below 70 dB(A) for the snowplow operator.

VIBRATION

Operating snowplow vibration does not exceed 2.5 m/s² to the hand-arm or 0.5 m/s² to the whole body.

TORQUE CHART

⚠ CAUTION

Read instructions before assembling. Fasteners should be finger tight until instructed to tighten according to torque chart. Use standard methods and practices when attaching snowplow, including proper personal protective safety equipment.

Recommended Fastener Torque Chart					
Inch Fasteners Grade 5 and Grade 8					
Size	Torque (ft-lb)		Size	Torque (ft-lb)	
	 Grade 5	 Grade 8		 Grade 5	 Grade 8
1/4-20	8.4	11.9	9/16-12	109	154
1/4-28	9.7	13.7	9/16-18	121	171
5/16-18	17.4	24.6	5/8-11	150	212
5/16-24	19.2	27.3	5/8-18	170	240
3/8-16	30.8	43.6	3/4-10	269	376
3/8-24	35.0	49.4	3/4-16	297	420
7/16-14	49.4	69.8	7/8-9	429	606
7/16-20	55.2	77.9	7/8-14	474	669
1/2-13	75.3	106.4	1-8	644	909
1/2-20	85.0	120.0	1-12	704	995
Metric Fasteners Class 8.8 and 10.9					
Size	Torque (ft-lb)		Size	Torque (ft-lb)	
	 Class 8.8	 Class 10.9		 Class 8.8	 Class 10.9
M6 x 1.00	7.7	11.1	M20 x 2.50	325	450
M8 x 1.25	19.5	26.9	M22 x 2.50	428	613
M10 x 1.50	38.5	53.3	M24 x 3.00	562	778
M12 x 1.75	67	93	M27 x 3.00	796	1139
M14 x 2.00	107	148	M30 x 3.50	1117	1545
M16 x 2.00	167	231	M33 x 3.50	1468	2101
M18 x 2.50	222	318	M36 x 4.00	1952	2701
These torque values apply to fasteners except those noted in the instructions.					

HYDRAULIC SYSTEM

FloStat® HYDRAULIC SYSTEM SPECIFICATIONS

Pump Relief Valve Setting

- 1750 psi
- 2-1/2 turns CCW from fully seated

System Capacity

- Unit reservoir: 1-3/4 quarts
- System total: 2-3/8 to 2-3/4 quarts

Solenoid Valve Spool Travel

- 0.07" for three- and four-way valves (S2, S3)

⚠ CAUTION

Do not mix different types of hydraulic fluid. Some fluids are not compatible and may cause performance problems and product damage.

Hydraulic Fluid

Use WESTERN® Hydraulic Fluid to –40°F (–40°C) or other fluid conforming to military specification MIL-H-5606 A, such as Mobil Aero HFA or Shell AeroShell® Fluid 4. Use of products other than these recommended fluids may cause poor hydraulic system performance and damage to internal components.

Motor/Hydraulic Specifications

12V DC with +/- connection
4.5" dia 1.5 kW motor
1750 psi pump relief valve
4000 psi angling relief valve
0.000477 gal/rev pump
Hydraulic Hose 1/4 SAE 100R1 and 3/8 SAE 100R17

Electrical System (approximate)

- Solenoid Coil Resistance @ R.T. = 6.7 ohm
- Solenoid Coil Amperage Draw = 1.5A
- Motor Relay Coil Resistance = 16–17 ohm
- Motor Relay Amperage Draw = 0.7A
- Maximum Motor Amperage Draw = 185–200A over relief at 1750 psi
- Headlamp Relay Coil Resistance = 106 ohm
- Headlamp Relay Amp Draw = 0.1A

Fastener Torque Specifications

Pump Cap Screws	5/16-18 x 2-1/2	150–160 in-lb
Motor Terminals (+ and –)	5/16-18 Nut	50–60 in-lb
Motor to Manifold Cap Screws	1/4-20 x 6-1/4	30–40 in-lb
Reservoir Screws		15–20 in-lb
Valve Cartridges		115–125 in-lb
Coil Nuts	3/4 Hex-Head Jam Nut	48–60 in-lb
Cartridge/Coil Cover Screws		15–20 in-lb
O-Ring Boss Plug		60–70 in-lb

Vehicle Control Harness Fuses

- Harness = 6A (SFE-6)

Snowplow Type	Crossover Relief Valve Pressure (±100 psi)	Number of Turns Crossover Relief Valve is Backed Off (CCW) from Fully Seated *	Pump Relief Valve Pressure (±50 psi)	Number of Turns Pump Relief Valve is Backed Off (CCW) from Fully Seated*	Max. Motor Amperage Draw at Relief Pressure**
Standard, Pro, PRO PLUS™	4000	1-1/4 – 1-1/2	1750	2-1/2 – 2-3/4	185 – 200


* Settings are approximate.

** Actual readings may vary due to vehicle battery voltage and oil temperature.

AeroShell® is a registered (®) trademark of Shell Oil Company.

HYDRAULIC SYSTEM

HYDRAULIC HOSE ROUTING AND FITTING INSTALLATION




10

Use the following procedure to install SAE O-Ring fittings in valve blocks and rams:

Back off jam nut. Hand tighten fitting into port until washer contacts port face, then back out to position. Using two wrenches, hold fitting body in position and tighten jam nut until the washer again contacts port face, then tighten additional 1/8 to 1/4 turn to lock fittings in place. Final torque on the jam nut should be approximately 20 ft-lb.






Use the following procedure to install hydraulic hoses:

Using two wrenches, hold the hose in position and tighten flare nut 1/8 to 1/4 turn beyond hand tight. Final torque on the flare nut should be approximately 20 ft-lb.




HYDRAULIC SYSTEM

HYDRAULIC UNIT PARTS DIAGRAM



HYDRAULIC SYSTEM


HYDRAULIC UNIT VALVE IDENTIFICATION AND LOCATION



NOTE: Breather is located at front of FloStat hydraulic unit.

HYDRAULIC SYSTEM


RELIEF VALVE IDENTIFICATION AND LOCATION



NOTE: Breather is located at front of FloStat® hydraulic unit.


HYDRAULIC SYSTEM

PILOT-OPERATED (POPPET-TYPE) CHECK VALVE IDENTIFICATION AND LOCATION



HYDRAULIC SYSTEM

VEHICLE HARNESS AND VEHICLE CABLE DIAGRAM



OPERATING THE SNOWPLOW

JOYSTICK CONTROL


⚠ WARNING

The driver shall keep bystanders clear of the blade when it is being raised, lowered, or angled. Do not stand between vehicle and blade or within 8 feet of a moving blade. A moving or falling blade could cause personal injury.

⚠ WARNING

To prevent accidental movement of the blade, always push the ON/OFF button to switch the control OFF whenever the snowplow is not in use. The power indicator light will turn OFF.

Turn the vehicle ignition switch to the ON or the ACCESSORY position. Move control ON/OFF switch to the ON position. The control indicator light (red) should light whenever the control ON/OFF switch and the ignition (key) are both turned ON.



Turn the vehicle ignition switch ON. Turn the control ON. The control indicator light should be on.	
Action	Description of Operation
ON/OFF	Slide the control power switch ON to activate the hydraulic system. Turn the control OFF to lock the blade in place. This will prevent accidental movement of the blade.
Raise	Move the control lever up (forward) to raise the blade to the desired height.
Lower/Float	Move the control lever down (back) to lower the blade and activate the FLOAT mode.
To Cancel FLOAT	The FLOAT mode can be canceled by either momentarily placing the control in the RAISE position, turning the control OFF or turning the vehicle ignition OFF. Angling left or right will not cancel float.
Right	Move the control lever right to angle the blade to the right.
Left	Move the control lever left to angle the blade to the left.

OPERATING THE SNOWPLOW


HAND-HELD CONTROL

⚠ WARNING

The driver shall keep bystanders clear of the blade when it is being raised, lowered, or angled. Do not stand between vehicle and blade or within 8 feet of a moving blade. A moving or falling blade could cause personal injury.

⚠ WARNING

To prevent accidental movement of the blade, always push the ON/OFF button to switch the control OFF whenever the snowplow is not in use. The power indicator light will turn OFF.



1. Turn the vehicle ignition switch to the ON or the ACCESSORY position. The control logo area will become illuminated.
2. Press the ON/OFF button on the control. The control indicator light will glow red indicating the control is on. The control indicator light will glow red whenever the control ON/OFF switch and the vehicle ignition switch are both ON.
3. Pressing the LOWER button for 0.75 second will engage the FLOAT mode. The control indicator FLOAT light will glow. Cancel the FLOAT mode by momentarily pressing the RAISE button.

Function Time Outs

All control functions, except for LOWER, automatically time out – stop – after a period of time. This is to prevent unnecessary battery drain. The time-out period for the RAISE function is 4.8 seconds, while the angle function is 9.6 seconds.

The control will automatically turn off after being idle for 20 minutes.

Smooth Stop

The control automatically allows the blade to coast to a stop. This results in smoother operation, reduces the shock to the hydraulic system and increases hose and valve life.

Button	Description of Operation
Raise	Press this button to raise the snowplow and to cancel the float mode. NOTE: Snowplow automatically stops raising after 4.8 seconds. To resume raising the snowplow, release the button and press again.
Lower/Float	Press this button to lower the snowplow. NOTE: After reaching the desired height, release the button. Holding the button down for more than 0.75 seconds activates the float mode, indicated by green FLOAT lamp.
To Cancel FLOAT	Cancel the float mode by momentarily pressing the RAISE button, turning control OFF, or turning vehicle ignition OFF. Angling left or right momentarily cancels float.
Right	Press this button to angle blade to the right.
Left	Press this button to angle blade to the left.

THEORY OF OPERATION

SNOWPLOW HEADLAMPS

The type of headlamp circuit varies depending on the make/model/year of vehicle and whether or not it is equipped with Daytime Running Lights (DRLs). The headlamp switching circuit uses two or more relays. When combined with the plug-in headlamp harness, plow light harness and vehicle harness, the relays automatically switch between vehicle and snowplow headlamps as the harness plugs are connected and disconnected.

Vehicles with Daytime Running Lights (DRLs) require a DRL kit which is an additional fused pink wire used in place of the brown wire.

SNOWPLOW PARK/TURN LAMPS

In an ordinary installation, the snowplow Park/Turn lamps are wired in parallel with the corresponding vehicle circuits. Some installations on trucks with clearance lights require an optional Park/Turn Relay Kit which allows the snowplow park lamps to operate directly off the battery, using the vehicle circuit to power only the relay. In either case, the vehicle and snowplow park and turn lamps will operate simultaneously.

The headlamp wiring schematics and electrical information included in this manual are typical for most 1998 and older vehicles. For 1999 and newer vehicles, refer to the snowplow Installation Instructions or *Electrical Schematics Guide*.

SNOWPLOW HYDRAULICS

The snowplow hydraulic system performs four blade movement functions. All functions require the vehicle ignition (key) switch to be in the run position and the cab control to be turned ON.

The cab control supplies power to the motor relay and the three solenoid cartridge valves in various combinations to direct hydraulic fluid to the snowplow lift and angle cylinders or back to the reservoir.

Raise and angle functions require both the motor and solenoid cartridge valve(s) to activate, while the lower function only requires activation of a solenoid cartridge valve. The motor and valves are deactivated when the cab control button or lever is released. The high amperage motor power circuit is completed through the battery cables when the motor relay is activated. The motor relay and solenoid cartridge valve circuits are low amperage, high side drive, and are completed when the cab control is activated.

Proper operation of the snowplow hydraulic system depends on the vehicle's ability to provide adequate electrical power. Electrical loads from the snowplow, vehicle and accessories can substantially reduce the vehicle system voltage if the charging system cannot meet the electrical demand. A low voltage condition can cause intermittent snowplow operation because the magnetic field produced in the solenoid cartridge valve coils may not be strong enough to shift the valves. Because of many variables, it is impossible to determine the point at which the system voltage is too low to consistently operate the snowplow.

This condition can be difficult to diagnose because the coil magnetism can still be detected and no problem exists in the hydraulic system. Do not overlook the fact that an apparent problem with the snowplow can actually be caused by low voltage in the vehicle electrical system. Consult a vehicle repair manual for electrical system specifications.



HYDRAULIC AND ELECTRICAL SCHEMATICS

LEGEND – ELECTRICAL & HYDRAULIC SYMBOLS

The following section contains hydraulic and electrical schematics to help explain how the hydraulic unit performs the different functions. A schematic is an abstract drawing showing the purpose of each of the components in the system. Each component is represented by a graphical symbol. The hydraulic and electrical legends list and describe each of the symbols used in the schematics for this guide. The first two schematics show a general overview of the complete hydraulic and electrical systems. The remainder of the schematics have been altered to highlight flow of hydraulic oil and electrical current for each function the hydraulic unit performs or flow of electrical current for the snowplow and vehicle lights.

- Bold lines represent the circuit being activated only.
- Shaded components are either activated or shifted from their normal position.


NOTE: Left side = Driver's side
Right side = Passenger's side

HYDRAULIC LEGEND		ELECTRICAL LEGEND	
	LINE, WORKING (MAIN)		SPRING
	LINE, PILOT (FOR CONTROL)		SOLENOID, SINGLE WINDING
	LINES JOINING		PILOT OPERATED (P/O) CHECK VALVE
	LINES CROSSING		VALVE, ADJUSTABLE PRESSURE RELIEF
	FLOW, DIRECTION OF HYDRAULIC FLUID		VALVE, FLOW CONTROL, ADJUSTABLE-NON-COMPENSATED
	LINE, TO RESERVOIR BELOW FLUID LEVEL		VALVE, TWO POSITION TWO CONNECTION (TWO WAY) S1
	HYDRAULIC PUMP FIXED DISPLACEMENT		VALVE, TWO POSITION THREE CONNECTION (THREE-WAY) S2
	CYLINDER		VALVE, TWO POSITION FOUR CONNECTION (FOUR-WAY) S3
	ELECTRIC MOTOR		CHECK VALVE
	FILTER, STRAINER DIFFUSER		COMPONENT ENCLOSURE
	CROSSING WIRE		WIRE SPLICE
	IN LINE CONNECTOR		RING TERMINAL
	FUSE		SOLENOID
	DIODE		CIRCUIT GROUND
	MOTOR RELAY		BATTERY
	MOTOR		PARK/TURN LAMP
	HEADLAMP		COMPONENT ENCLOSURE

Wire Color Code				Abbreviations					
BLK	Black	BRN/GRN	Brown w/Green	LTBLU	Light Blue	PUR	Purple	DRL	Daytime
BLK/ORN	Black w/Orange	BRN/RED	Brown w/Red	LTGRN	Light Green	RED	Red		Running
BLK/RED	Black w/Red	DKBLU	Dark Blue	LTBLU/ORN	Light Blue w/Orange	TAN	Tan		Lights
BLK/WHT	Black w/White	DKBLU/ORN	Dark Blue w/Orange	LTBLU/WHT	Light Blue w/White	VIO	Violet	MTR RLY	Motor
BLU	Blue	DKBLU/WHT	Dark Blue w/White	ORN	Orange	WHT	White		Relay
BLU/ORN	Blue w/Orange	GRN	Green	ORN/BLK	Orange w/Black	WHT/YEL	White w/Yellow	P/T SIG	Park/Turn
BRN	Brown	GRY	Gray	PNK	Pink	YEL	Yellow		Signal

HYDRAULIC AND ELECTRICAL SCHEMATICS

HYDRAULIC SCHEMATIC



HYDRAULIC AND ELECTRICAL SCHEMATICS

RAISE – ELECTRICAL


Blade Movement: Raise

Control: Raise

System Response:


1. By moving control lever or pressing the control button, the circuit board within the cab control supplies power for the electrical circuits.

2. Electrical current flows through the motor relay, activating the pump motor, and solenoid cartridge valve S3, shifting the spool.
3. Hydraulic fluid from the pump flows through the solenoid cartridge valves S3 & S2 and the internal check valve in solenoid cartridge valve S1, and into the lift cylinder causing it to extend.



HYDRAULIC AND ELECTRICAL SCHEMATICS

RAISE – HYDRAULIC



BLADE MOVEMENT		RAISE	LOWER	ANGLE RIGHT	ANGLE LEFT
					
MOTOR	M	ON		ON	ON
SV08-2004	S1		ON		
SV08-31	S2			ON	ON
SV08-40	S3	ON			ON

HYDRAULIC AND ELECTRICAL SCHEMATICS

LOWER – ELECTRICAL

Blade Movement: Lower / Float


Control: Lower

System Response:

1. By moving control lever or pressing the control button, the circuit board within the cab control supplies power for the electrical circuit.
2. Electrical current flows through solenoid cartridge valve S1, shifting the spool.


3. The weight of the plow forces the lift cylinder to retract. The retracting lift cylinder pushes the hydraulic fluid through solenoid cartridge valves S1 & S2 & S3, and back to the reservoir.

NOTE: CabCommand hand-held control only – while in FLOAT, angling right or left will temporarily cancel FLOAT (turn OFF solenoid cartridge valve S1) until the angle button is released.



HYDRAULIC AND ELECTRICAL SCHEMATICS

LOWER – HYDRAULIC



HYDRAULIC AND ELECTRICAL SCHEMATICS


ANGLE RIGHT – ELECTRICAL

Blade Movement: Angle Right

Control: Right

System Response:


1. By moving control lever or pressing the control button, the circuit board within the cab control supplies power for the electrical circuit.
2. Electrical current flows through the motor relay, activating the pump motor, and solenoid cartridge valve S2, shifting its spool.
3. Hydraulic fluid from the pump flows through the solenoid cartridge valve S3 and the poppet check valve, and into the base end of the left cylinder, causing it to extend.
4. The retracting right cylinder pushes the hydraulic fluid out of its base end, through solenoid cartridge valves S2 & S3 back to the reservoir.



BLADE MOVEMENT
ANGLE RIGHT

HYDRAULIC AND ELECTRICAL SCHEMATICS

ANGLE RIGHT – HYDRAULIC



HYDRAULIC AND ELECTRICAL SCHEMATICS


ANGLE LEFT – ELECTRICAL

Blade Movement: Angle Right

Control: Right


System Response:

1. By moving control lever or pressing the control button, the circuit board within the cab control supplies power for the electrical circuit.
2. Electrical current flows through the motor relay, activating the pump motor, and solenoid cartridge valve S2, shifting its spool.
3. Hydraulic fluid from the pump flows through the solenoid cartridge valve S3 and the poppet check valve, and into the base end of the left cylinder, causing it to extend.
4. The retracting right cylinder pushes the hydraulic oil out of its base end, through solenoid cartridge valves S2 & S3 back to the reservoir.



HYDRAULIC AND ELECTRICAL SCHEMATICS

ANGLE LEFT – HYDRAULIC



BLADE MOVEMENT		RAISE	LOWER	ANGLE RIGHT	ANGLE LEFT
					
MOTOR	M	ON		ON	ON
SV08-2004	S1		ON		
SV08-31	S2			ON	ON
SV08-40	S3	ON			ON

HYDRAULIC AND ELECTRICAL SCHEMATICS


HOLD IN RAISE POSITION – HYDRAULIC

Blade Movement: Hold in Raised Position

Control: None

System Response:

Hydraulic fluid is trapped in the lift cylinder by the internal check valve in solenoid cartridge valve S1.



BLADE MOVEMENT		RAISE	LOWER	ANGLE RIGHT	ANGLE LEFT
MOTOR	M	ON		ON	ON
SV08-2004	S1		ON		
SV08-31	S2			ON	ON
SV08-40	S3	ON			ON

HYDRAULIC AND ELECTRICAL SCHEMATICS


STRIKING AN OBJECT WHILE PLOWING – LEFT HYDRAULIC CYLINDER RETRACTS

Blade Movement: Striking an Object While Plowing

Control: None

System Response:

1. Hydraulic fluid is trapped in the base end of the cylinders by the relief valves, the poppet check valve and solenoid cartridge valve S2.
2. When the plow contacts an object, the force of the impact increases the hydraulic pressure in the base end of the cylinder. When the pressure exceeds the relief valve pressure setting, the relief valve opens allowing oil flow to the base of the opposite cylinder.



BLADE MOVEMENT		RAISE	LOWER	ANGLE RIGHT	ANGLE LEFT
MOTOR	M	ON		ON	ON
SV08-2004	S1		ON		
SV08-31	S2			ON	ON
SV08-40	S3	ON			ON

HYDRAULIC AND ELECTRICAL SCHEMATICS


STRIKING AN OBJECT WHILE PLOWING – RIGHT HYDRAULIC CYLINDER RETRACTS

Blade Movement: Striking an Object While Plowing

Control: None


System Response:

1. Hydraulic fluid is trapped in the base end of the cylinders by the relief valves, the poppet check valve and solenoid cartridge valve S2.
2. When the plow contacts an object, the force of the impact increases the hydraulic pressure in the base end of the cylinder. When the pressure exceeds the relief valve pressure setting, the relief valve opens allowing oil to flow to the base of the opposite cylinder.




HYDRAULIC AND ELECTRICAL SCHEMATICS

HEADLAMPS – PLOW NOT CONNECTED – 9-PIN (TYPICAL)




HYDRAULIC AND ELECTRICAL SCHEMATICS

HEADLAMPS – PLOW NOT CONNECTED – 12-PIN (TYPICAL)




HYDRAULIC AND ELECTRICAL SCHEMATICS

HIGH BEAM HEADLAMPS – PLOW CONNECTED – 9-PIN (TYPICAL)




HYDRAULIC AND ELECTRICAL SCHEMATICS

HIGH BEAM HEADLAMPS – PLOW CONNECTED – 12-PIN (TYPICAL)




HYDRAULIC AND ELECTRICAL SCHEMATICS

LOW BEAM HEADLAMPS – PLOW CONNECTED – 9-PIN (TYPICAL)



HYDRAULIC AND ELECTRICAL SCHEMATICS

LOW BEAM HEADLAMPS – PLOW CONNECTED – 12-PIN (TYPICAL)



TROUBLESHOOTING GUIDE

INTRODUCTION

This guide consists of a series of tables, diagrams, flow charts and other information. When used properly it will assist the mechanic in identifying and repairing malfunctioning system components. Western Products highly recommends the use of the UniMount®/UltraMount® Electrical Tester as a timesaving option for electrical system diagnosis. When using this tester, refer to the supplied instruction manual for proper use of the tester.

Any malfunction of the snowplow can be categorized as either mechanical, electrical, or hydraulic. Mechanical issues are generally related to the blade, framework and mount components and are usually identified by visual inspection. Electrical and hydraulic issues can sometimes be difficult to trace to the component level and that is the purpose of this troubleshooting guide.

Read and understand the Theory of Operation before attempting troubleshooting.

TROUBLESHOOTING GUIDE

How to Use the Troubleshooting Guide

When diagnosing the snowplow electrical and hydraulic systems, many variables need to be eliminated in order to obtain workable test procedures. These variables translate into conditions listed before the tables or flow charts and must be satisfied before proceeding.

If the listed conditions are not met, the procedure can result in inaccurate results and wasted time.

In many cases, satisfying the listed conditions alone will solve the problem.

1. Go to the General Diagnostic Table and satisfy the nine listed conditions. These conditions must be met before proceeding into the table or to any subsequent test.
2. Locate the condition in the table which best describes the problem and check possible causes and actions in the order listed.
3. Proceed to a service procedure, another condition, or a specific test as directed. All tests except the Hydraulic System Test use a flow chart format. To use these flow charts, first satisfy any listed conditions at the top of the page. Then begin at the upper left square and proceed as directed.
4. Follow along sequentially through the table and tests, referring to the hydraulic and electrical schematics in the Theory of Operation section and the component Identification and Location diagrams. Eventually the problem will be pinpointed at the component level.

Electrical Testing

Read and understand the Theory of Operation section. A simple 12V test light with a ground lead can be used for circuit testing. When directed to check for 12 volts (12V), ground the test lamp lead and probe the terminal. When asked to check for ground, attach the test lamp lead to +12V and probe the terminal.

NOTE: 12V is a nominal value. If using a voltmeter, actual voltage will vary with the vehicle and presence of loads in tested circuits. Continuity alone does not guarantee a good circuit. Poor connectors or damaged wires may have continuity but be unable to carry sufficient current.

TROUBLESHOOTING GUIDE

Before You Begin

Before proceeding, or carrying out any tests, you *must* perform the following steps:

1. **Verify** that the customer has accurately and completely described the problem. **Observe** all lighting and snowplow functions.
2. **Check the obvious**, to confirm that:
 - a. The snowplow is attached to the vehicle and all harnesses are connected.
 - b. The ignition is turned ON (or the engine is running, if operating the control from within the cab).
 - c. The control is connected in the cab and turned ON. The control power LED is in a steady state and is not flashing.
 - d. The fuses are good.

- e. The vehicle battery and charging system are in good condition, and battery connections are clean and tight.
- f. Harness connector pins and terminals are free of corrosion, ensuring good connections, and coated with dielectric grease.

- g. The hydraulic reservoir is filled to the proper level with recommended fluid when the lift ram is fully retracted. (See Product Specifications.)
- h. There are no fluid leaks from hoses, fittings, rams or the hydraulic unit.
- i. All hoses are routed correctly.
- j. Coil wire connections are secure and correct.
- k. Correct cartridges are installed in the proper locations.
- l. All built up snow and ice is removed from the snowplow.
- m. 6A fuse in vehicle harness is good.

⚠ CAUTION
Fill the reservoir to the fill level only. Do not overfill. Overfilling could damage the unit.

⚠ CAUTION
Do not mix different types of hydraulic fluid. Some fluids are not compatible and may cause performance problems and product damage.

CONDITION	POSSIBLE CAUSE	ACTION
Motor does not run for any requested function.	Poor connections in vehicle or snowplow battery cables.	Clean and re-establish connections.
	Motor worn or damaged or pump seized.	Go to Motor Test.
	Motor relay inoperative.	Go to Motor Relay Test.
	Open circuit in vehicle wiring harness.	Go to Vehicle Harness Test – Motor Relay.
	Malfunctioning control.	Go to Control Test.
Motor runs continuously.	Motor relay sticking or always energized.	Go to Motor Relay Test.
	Short circuit in vehicle wiring harness.	Go to Vehicle Harness Test – Motor Relay.
	Malfunctioning control.	Go to Control Test.
Snowplow won't raise – motor runs.	Clogged pump filter (all functions are affected).	Clean or replace filter, flush reservoir.
	Pump relief low. Worn or damaged pump.	Go to Pump Pressure Test.
	Poor connections on battery cables.	Inspect battery cables, clean and re-attach all connections.

TROUBLESHOOTING GUIDE

GENERAL DIAGNOSTIC TABLE

CONDITION	POSSIBLE CAUSE	ACTION
Snowplow won't raise – motor runs (continued).	Solenoid valve coil not activating properly.	Go to Solenoid Coil Activation Test.
	Hydraulic system malfunction.	Go to Hydraulic System Test.
	Malfunctioning controller.	Go to Control Test.
Snowplow raises slowly or partially – motor runs.	Clogged pump filter (all functions are affected).	Clean or replace filter, flush reservoir.
	Pump relief low. Worn or damaged pump.	Go to Pump Pressure Test.
	Poor connections on battery cables.	Inspect battery cables, clean and re-attach all connections.
	Slow motor RPM.	Repair or replace motor.
	Air in lift cylinder.	Check diffuser screen. Fully collapse lift cylinder to purge air.
	Malfunctioning control.	Go to Control Test.
Snowplow will not lower or lowers slowly, or won't float.	Quill adjusted in too far.	Adjust quill out.
	Solenoid valve coils not activating properly.	Go to Solenoid Coil Activation Test.
	Hydraulic system malfunction.	Go to Hydraulic System Test.
Snowplow angles slowly.	Clogged pump filter (all functions are affected).	Clean or replace filter, flush reservoir.
	Pump relief low. Worn or damaged pump.	Go to Pump Pressure Test.
	Poor connections on battery cables.	Inspect battery cables, clean and re-attach all connections.
	Slow motor RPM.	Repair or replace motor.
	Air in angle cylinder.	Check diffuser screen. Cycle angle functions to purge air.
	Oil bypassing cylinder relief valve.	Go to Relief Valve Inspection and Adjustment.
	Malfunctioning PO check valve.	Go to Pilot Operated Check Valve Test and Inspection.
Blade will not hold angled position.	Air in angle cylinders.	Check diffuser screen. Cycle angle functions to purge cylinders.
	Oil bypassing cylinder relief valve.	Go to Relief Valve Inspection and Adjustment.
	Hydraulic system malfunction.	Go to Hydraulic System Test.
Plow does not perform the selected function or performs a different function.	Hydraulic hose routing incorrect.	Verify correct hose installation. See Hose Routing Diagram.
	Solenoid valve coils not activating properly.	Go to Solenoid Coil Activation Test.
	Hydraulic system malfunction.	Go to Hydraulic System Test.
	Malfunctioning control.	Go to Control Test.

TROUBLESHOOTING GUIDE

GENERAL DIAGNOSTIC TABLE


CONDITION	POSSIBLE CAUSE	ACTION
Vehicle harness 6A fuse blows.	Red wire in vehicle harness is shorted to ground.	Repair wire or replace vehicle harness.
	Motor relay primary coil shorted internally.	Check primary coil with ohmmeter. Replace defective motor relay.
	Solenoid valve coil shorted internally.	Go to individual coil test. Replace shorted coils.
	Motor relay or solenoid coil wires in vehicle harness shorted to ground.	Repair wire or replace vehicle harness.
	Solenoid coil wires in plow harness shorted to ground.	Repair wire or replace plow harness.
	Malfunctioning control.	Go to Control Test.
Vehicle accessory fuse blows.	Circuit overloaded.	Consult vehicle owner's manual for correct application of aftermarket electrical loads.
Excessive load on vehicle electrical system while using snowplow.	Poor connections in battery cables.	Inspect battery cables, clean and re-establish all connections.
	Pump relief incorrectly adjusted.	Go to Pump Pressure Test.
	Worn or damaged pump or motor.	Go to Pump Pressure Test/check motor.
Snowplow headlamps operate irregularly or not at all – snowplow attached. –or– Vehicle headlamps operate irregularly or not at all – snowplow removed.	Burned out bulbs or corroded sockets.	Replace bulbs, clean contacts.
	Wires improperly connected to relays.	Review and correct wire installation. See Headlamp Test Diagram.
	Headlamp relay inoperative.	Go to Plow Headlamp Test or Vehicle Headlamp Test.
Vehicle daytime running lamps (DRLs) do not work – snowplow removed ('98 and older vehicles).	Parking brake on. Or see vehicle Owner's Manual for Proper Operation.	Fully release parking brake.
	Power in DRL circuit has been interrupted.	Turn lamp and/or ignition switch ON and OFF to cycle the DRL circuitry.
	No output from DRL module.	Repair vehicle electrical system.
Snowplow Park or Turn lamps operate intermittently or not at all – snowplow attached.	Burned out bulb, corroded socket(s) or poor electrical connection.	Replace bulbs/clean contacts. If necessary, go to Park/Turn Lamp Test.

TROUBLESHOOTING GUIDE

HYDRAULIC RAMS—INSPECTION AND REPAIR

General

The lift and angling rams use a gland nut with rod seal and o-ring instead of a packing set and adjustable packing nut. The gland nut is torqued onto the cylinder coupling and requires no adjustment. Periodically inspect rams for leakage. A slight amount of oil weep along the rod is normal and may leave an oil film around the gland nut. If oil is dripping off the gland nut or the wiper is extruded or folded in, the ram should be repaired.



Disassembly

1. Lower blade to ground and turn OFF vehicle ignition.
2. Before removing ram from snowplow, break gland nut loose with a 2-3/16" open-end wrench. If a pipe wrench must be used, set jaws squarely against flats of nut and apply steady force. Gland nut break-loose torque usually exceeds 200 ft-lb.
3. Remove ram and collapse to drain oil.
4. Remove gland nut and rod as an assembly. Remove split bearing and spacer and slide gland nut off bearing end of rod.
5. Remove O-ring, wiper, and seal from gland nut and discard them. Avoid scratching or damaging O-ring, wiper, and seal grooves.
6. Check screen in ram base for contaminants. Wash out and identify any foreign material to determine if further corrective action is needed.

45

⚠ CAUTION

If snowplow is not attached to vehicle, install support blocking under 1-1/2" round cross tube at rear of lower lift frame before removing lift ram or lift chains.

TROUBLESHOOTING GUIDE

HYDRAULIC RAMS—INSPECTION AND REPAIR


Inspection

1. Cylinder wall should be straight and free of any deep gouges or displaced material. O-ring chamfer and coupler end surface should be clean and smooth.
2. Split bearing sections and spacer should be free of burrs and sharp edges.
3. Check rod for rust or nicks that can damage the seal.
4. Gland nut O-ring, wiper, and seal grooves must be clean, smooth, and free of burrs. If O-ring flange is cracked or broken, replace gland nut.

Assembly

1. Always use a new seal, wiper and O-ring. Lubricate with clean hydraulic oil and assemble by hand to avoid seal damage. Be sure seal lip is toward the inside of the cylinder and the O-ring "spring" inside the seal remains in position. Follow instructions in the seal kit.

2. Lubricate bearing end of rod and insert into wiper end of gland nut. Press nut onto rod by hand, making sure the outer lip of the wiper does not fold in. Never slide nut over pin end of rod; this will damage the seal. Slide nut to middle of rod.
3. Assemble spacer and split bearing. Hold rod vertically so spacer holds bearing and assemble to cylinder. Tighten gland nut to 150–180 ft-lb. If a socket and torque wrench are not available, tighten nut by hand against a .012 feeler gauge between coupler and nut flange, remove gauge and tighten nut an additional 1/4 turn. This procedure is best accomplished with ram installed on snowplow.
4. Reinstall ram. For angle ram, align fitting 20° to the rear of vertical when ram is horizontal. For lift ram, with fitting to rear, align fitting to the passenger's side. See section on installing fittings and hoses for proper procedure.
5. Activate blade several times and fully collapse lift ram manually to remove air. Refill reservoir.




TROUBLESHOOTING GUIDE

MOTOR TEST

⚠ WARNING


The driver shall keep bystanders clear of the blade when it is being raised, lowered, or angled. Do not stand between vehicle and blade or within 8 feet of a moving blade. A moving or falling blade could cause personal injury.

Refer to the Motor and Motor Relay Test Diagram on following page.



TROUBLESHOOTING GUIDE

Motor And Motor Relay Test Diagram



TROUBLESHOOTING GUIDE


MOTOR RELAY TEST

⚠ WARNING

The driver shall keep bystanders clear of the blade when it is being raised, lowered, or angled. Do not stand between vehicle and blade or within 8 feet of a moving blade. A moving or falling blade could cause personal injury.


1. Momentarily jump power and ground directly from battery to motor to verify that the motor runs. Make final connection at the motor.
2. Refer to the Motor and Motor Relay Test Diagram, and Vehicle Harness and Vehicle Cable Location Diagram.

Motor does not run:



49

Motor runs continuously:



TROUBLESHOOTING GUIDE


VEHICLE HARNESS TEST – MOTOR RELAY

⚠ WARNING


The driver shall keep bystanders clear of the blade when it is being raised, lowered, or angled. Do not stand between vehicle and blade or within 8 feet of a moving blade. A moving or falling blade could cause personal injury.

1. Perform the Motor Test and Motor Relay Test first.
2. Disconnect the control in the cab.
3. Refer to the 6-Pin Connector diagram. Test the vehicle side of the connector in the cab as follows.

**White 6-Pin Connector
on vehicle harness –
located in cab
(end view)**



Pin #	Wire Color
1	Red
2	Lt Green
3	Orange/Black
4	Brown/Red
5	Lt Blue
6	White/Yellow




TROUBLESHOOTING GUIDE

CONTROL TEST

Test Procedure for Hand-Held or Solenoid Control

1. Disconnect the control in the cab and remove to work bench.
2. Refer to the 6-Pin Connector diagram and the chart.
3. Using a 12V power source with a 6A fuse in the positive lead, carefully apply +12V to pin #1 and ground to pin #3 of the 6-pin connector.
4. Turn the control ON. Power indicator lamp should be lit. Check for 12V at each of pins #2, 4, 5, 6 when the control is activated for each function. Footnotes in the chart indicate special conditions of control operation.
5. Compare the control outputs for all functions with the chart and proceed to the flow chart on the following page.




Wire Color		
Pin #	Solenoid Control	CabCommand
1	White	Black/White
2	Green	Red
3	Brown	Green
4	Black	Orange
5	Blue	Blue
6	Red	Yellow

Pin #	Purpose	Angle Right (c)	Angle Left (c)	Raise (d)	Lower/Float (e)
1	12V Input				
2	S2 Output (3-way)	ON	ON		
3	Ground				
4	Motor Relay Output	ON (b)	ON (b)	ON (b)	
5	S3 Output (4-way)		ON	ON	
6	S1 Output (2-way)	(a)	(a)		ON

- a. S1 output will be ON if control is in float. Activate raise function to cancel float. If hand-held control is in float, S1 output will turn off while angle button is pressed and on when the button is released.
- b. For hand-held control, motor relay output turns off before solenoid coil outputs when button is released.
- c. For hand-held control, outputs turn off after button is held for approximately 9.6 seconds.
- d. For hand-held control, outputs turn off after button is held for approximately 4.8 seconds.
- e. Solenoid control activates S1 output in float when lever is moved to lower position.
- f. Hand-held control activates float when lower button is held for 0.75 second.

TROUBLESHOOTING GUIDE

CONTROL TEST



NOTE: For hand-held control, poor ground connections or high or low voltage will shut the control off.

To Safely Handle Hand-Held Pcb:

⚠ CAUTION

Printed circuit board (PCB) is subject to damage from static electricity. Follow instructions below to safely handle PCB.

1. Disconnect the control in the cab and remove to a workbench.
2. Place control on its left side and remove right side of handle, leaving the keypad/circuit board assembly in left half.
3. Touch hand to any grounded metal object to discharge possible static buildup.
4. Remove keypad/circuit board assembly from housing by only touching the edges of the keypad/circuit board assembly.
5. The keypad/circuit board assembly can be handled safely as long as contact with it is maintained.

TROUBLESHOOTING GUIDE


PUMP PRESSURE TEST

⚠ WARNING

The tester shall keep bystanders 8' clear of the blade during these tests. Do not stand between vehicle and blade or within 8 feet of a moving blade. A moving or falling blade could cause personal injury.

1. Lower blade to the ground, place control in FLOAT mode, and fully collapse the lift ram.
2. Carefully disconnect either angle hose from the angle ram 90° fitting and install Pressure Testing Kit #56679 according to kit/instructions or refer to FloStat® Hydraulic Hose Routing and Fitting Installation instructions on page 7.
3. Route the end of the hose with gauge up to the headlamp crossbar and secure prior to testing.
4. Tighten hydraulic fittings to proper torque as described on page 7.
5. Activate the appropriate angle function with the control and read the pump relief pressure when the blade is fully angled.
6. Refer to the illustration for pump relief valve location. Adjust pump pressure according to chart value. Do not adjust relief valve while motor is running.
7. Proceed to the flow chart on the following page.


Plow Type	Maximum Motor Amperage Draw at 11.2V w/Warm Oil	Pump Relief Valve Pressure (± 50 psi)
Standard, Pro, PRO PLUS™	185 – 200	1750



TROUBLESHOOTING GUIDE

PUMP PRESSURE TEST

1. Be sure motor is in good condition.



TROUBLESHOOTING GUIDE

CARTRIDGE COIL ACTIVATION TEST

1. Disconnect the black/red POSITIVE (+) battery cable from the motor and isolate it.
2. Remove solenoid valve cover.
3. Verify wires are properly attached to solenoid coils. Refer to Wire Connection Table, Electrical Schematic, and Solenoid Cartridge Valve Identification and Location.
4. Activate the control for each function and check for magnetic pull at all three solenoid valve coils. Only the coils designated as "ON" in the table should activate for each function. After noting which coils are energized, proceed to the flow chart.


Cartridge Coil Wiring and Activation – Wire Connection Table

Solenoid Coil	Plow Harness Pin	Wire Color	Angle Right	Angle Left	Raise	Lower
S1 (2-way)	1	White/Yellow	*	*	*	ON
S2 (3-way)	3	Lt Green	ON	ON		
S3 (4-way)	4	Lt Blue		ON	ON	

*S1 output will be "ON" for all functions if control is in "FLOAT".

Activate "RAISE" function to cancel "FLOAT."

Hand Held Control Only – While in "FLOAT", pressing and holding the "RIGHT" or "LEFT" button will turn OFF the solenoid cartridge valve S1 until the button is released.




TROUBLESHOOTING GUIDE


VEHICLE HARNESS TEST – CARTRIDGE COILS

1. Disconnect the black/red POSITIVE (+) battery cable from the motor and isolate it.
2. Perform Cartridge Coil Activation Test.
3. Connect all harness connectors at the front of the vehicle.
4. Refer to the 6-Pin Connector diagram for socket location.

**White 6-Pin Connector
on vehicle harness –
located in cab
(end view)**



Pin #	Wire Color
1	Red
2	Lt Green
3	Orange/Black
4	Brown/Red
5	Lt Blue
6	White/Yellow



TROUBLESHOOTING GUIDE

HYDRAULIC SYSTEM TEST

This test consists of trying all the plow functions and comparing the plow reaction to the action requested in the following table. The table will pinpoint a solenoid valve or poppet check valve problem accurately if only one component is malfunctioning. If the snowplow reaction for a given function is not listed in the table, there may be a crossover relief or poppet check valve which is stuck open or contaminated, missing or damaged O-rings or backing rings on cartridge, crossover relief or poppet check valve spool, or there may be two or more malfunctioning components. In this case, use the specific function hydraulic schematic and carefully inspect each component in the flow circuit. If contamination is evident in more than one component, the hydraulic unit, hoses and cylinders must be completely disassembled, inspected, and cleaned.

1. Perform Cartridge Coil Activation Test first.
2. Verify hydraulic hose installation is correct. Refer to the Hose Routing diagram.
3. Test all of the snowplow functions.
4. Inspect and clean or replace the suspected component. Refer to the Hydraulic Parts Diagram – page 8.
5. Refer to the sections following the table for inspection and adjustment of solenoid cartridge valves, poppet check valve and crossover relief valves.

ACTION REQUESTED	PLOW REACTION	POSSIBLE CAUSE
Raise	None	S3 not shifted
	Angle Left	S2 stuck shifted
Lower	None	S1 not shifted
		S2 stuck shifted
		S3 stuck shifted
Angle Right	Angle Left	S3 stuck shifted
	None	S2 not shifted
	Slow	Poppet check valve not opening
Angle Left	Angle Right	S3 not shifted
	Raise	S2 not shifted
	None	S2 and S3 not shifted
	Slow	Poppet check valve not opening
None (blade raised)	Lowers	S1 stuck shifted or has leaking internal check valve
None	Drifts Right	S2 stuck shifted
		Contamination, bad valve stem seat, or damaged O-rings in crossover relief valve
	Drifts Left	Poppet check valve open
		Contamination, bad valve stem seat, or damaged O-rings in crossover relief valve

IMPORTANT: When testing the snowplow functions, be sure the control is not in "float."

TROUBLESHOOTING GUIDE

CROSSOVER RELIEF VALVE INSPECTION AND ADJUSTMENT

Crossover Relief Valve Inspection

1. Remove the valve stem, ball, spacer, and spring.
2. Look for broken or damaged parts, contamination, or missing or damaged O-rings. Check valve stem seat for excessive wear.

⚠ CAUTION

Be careful to strike the stem squarely. You can bend the stem if you do not strike it squarely.

3. If parts are in good condition, place ball on hard wood block, hold stem seat on ball, and strike stem lightly with a hammer. This will re-conform the seat to the ball.
4. Apply a light coat of anti-seize or grease to stem threads. Lubricate O-ring with hydraulic fluid. Reassemble components into valve block.


Adjustment

1. Adjust by tightening the relief valve stem until it bottoms out (until spring is fully compressed).
2. Back off valve stem (rotate counterclockwise) the number of turns indicated in the Crossover Relief Valve Settings table.

Crossover Relief Valve Settings

Plow Type	No. of Turns Backed Off (CCW) From Fully Seated*	Crossover Relief Valve Pressure (\pm 100 psi)
Standard, Pro, PRO PLUS™	1-1/4 – 1-1/2	4000

* Settings are approximate.




TROUBLESHOOTING GUIDE

PILOT-OPERATED (POPPET STYLE) CHECK VALVE TEST AND INSPECTION

Test

Remove poppet and poppet spring. Reinstall boss plug and test plow. If problem is corrected go to inspection.



Inspection

1. Strike boss plugs squarely with a hammer to facilitate removal.
2. Remove O-ring boss plug, spring, and poppet.
3. Remove O-ring boss plug, spring, and spool with O-ring. Use long/slender needle-nosed pliers to remove spool.
4. Inspect springs, poppet, spool, O-rings, and poppet seat for wear, damage, or contamination. Replace worn parts.
5. The valve manifold block has a pressed in steel poppet seat. Use a strong pencil magnet to push and pull on the seat. If the seat moves at all, replace the valve block. Never hammer on the seat or attempt to "coin" the poppet.
6. Re-oil O-rings, install spool fully into bore. Spool must insert smoothly.
7. Install poppet, springs, and O-ring boss plugs. Torque O-ring boss plug to 60 in-lb.

TROUBLESHOOTING GUIDE

INDIVIDUAL SOLENOID COIL TEST

1. Remove both wires from coil terminals.
2. Attach an ohmmeter across the coil terminals.
3. A reading of approximately 6.7 ohm indicates the coil is good. A good coil will draw approximately 1.5A.

SOLENOID CARTRIDGE VALVE INSPECTION


1. Remove coils from the solenoid cartridge valves and remove the cartridge valves from the manifold. Look for visible contamination or damaged seals. Check for stuck spools with a plastic, aluminum, or soft brass probe by pushing on the spring loaded internal spool from the end of the valve. The spool should move freely through its entire travel. Spool travel is approximately 0.070".

NOTE: Using probe to move spool may shear contamination which was affecting spool movement.

2. Bench test the cartridge valve by installing a coil on the stem and applying 12V and ground. Watch through the side ports for internal spool travel. If the cartridge valve spool is stuck or its travel is restricted, replace the cartridge. If the cartridge valve appears to be in good condition, clean it with parts cleaning solvent and dry with compressed air, being careful not to damage the seals. Check the spool travel again in case any internal contaminants were dislodged during cleaning.


Re-oil the cartridge valve seals and O-rings and reinstall the cartridge valve, torquing to 10 ft-lb. Install the coils and torque the retaining nuts to 4 ft-lb.

NOTE: If contamination is seen in more than one component, it can reasonably be assumed that the entire system is contaminated. In order to perform a proper repair, the entire hydraulic unit, including hoses and cylinders, must be disassembled and cleaned. The source of the contamination must be located and repaired before reassembly.



TROUBLESHOOTING GUIDE


HEADLAMP TEST DIAGRAM – 9-PIN HARNESS



TROUBLESHOOTING GUIDE

VEHICLE HEADLAMP TEST – 9-PIN HARNESS


1. Verify correct harness and wire installation to relays and vehicle headlamps. See the Headlamp Test Diagram – 9-Pin Harness. The specific wiring diagram for the vehicle can be found in the snowplow Installation Instructions, or the manual Electrical Schematics Guide.
2. Turn ignition and headlight switch ON.
3. Disconnect all harnesses at the front of the vehicle.
4. All bulbs must be good.



TROUBLESHOOTING GUIDE

PLOW HEADLAMP TEST – 9-PIN HARNESS




1. Verify correct harness and wire installation to the headlamp relays.
2. All bulbs must be good.
3. Connect all harnesses at the front of the vehicle.
4. Turn vehicle headlamp switch on. For vehicles with Daytime Running Lamps (DRLs), turn ignition ON. DRL-equipped vehicles have a pink wire instead of a brown wire on relay terminal 86.
5. Refer to the 9-Pin Electrical Schematic Headlamp Test Diagram – 9-Pin Harness, and Connector diagram. The specific wiring diagram for the vehicle can be found in the snowplow Installation Instructions, or the manual Electrical Schematics Guide.



TROUBLESHOOTING GUIDE

PARK/TURN LAMP TEST – 9-PIN OR 12-PIN HARNESS

1. Verify plow park/turn (P/T) bulbs and contacts are good.
2. Turn parking lamps and ignition ON.
3. Connect all harnesses at the front of the vehicle.
4. Refer to the Vehicle Harness 9- or 12-Pin Connector diagram.




TROUBLESHOOTING GUIDE

OPTIONAL PARK/TURN RELAY KIT TEST

1. Turn signal applications use both gray and purple relay circuits.
2. Park lamp applications use gray relay circuit only. If gray relay circuit fails, purple relay circuit can be used instead.
3. Refer to the Optional Park/Turn Relay Kit schematic.
4. Verify that the relay kit red and black wires are connected to battery POSITIVE (+) and NEGATIVE (-) terminals respectively.
5. Verify in-line 10A fuse in red wire is good.
6. Disconnect long and short gray and purple wires to isolate relay circuits.


NOTE: If the snowplow park/turn lamps are on when the vehicle park/turn lamps are off, replace the relay kit.




TROUBLESHOOTING GUIDE

OPTIONAL PARK/TURN RELAY KIT SCHEMATICS

WIRED FOR PARK LAMPS




WIRED FOR TURN SIGNALS



TROUBLESHOOTING GUIDE


VEHICLE HEADLAMP TEST – 12-PIN HARNESS – 3-RELAY SYSTEM ONLY

1. Verify correct harness and wire installation to headlamp relays, vehicle headlamps, and vehicle headlamp connectors.
2. All bulbs must be good.
3. Disconnect all harnesses at the front of the vehicle.
4. Turn vehicle headlamp switch on. For vehicles with Daytime Running Lamps (DRLs), turn ignition ON. DRL equipped vehicles have a pink wire instead of a brown wire on relay terminal 86.
5. Verify power for both high and low beam and ground are present at the original vehicle headlamp connectors.
6. Refer to the Electrical Schematic – 12-Pin Harness, and the Headlamp Test Diagram 12-Pin Harness. The specific wiring diagram for the vehicle can be found in the plow installation instructions, or the manual Electrical Schematics Guide.



TROUBLESHOOTING GUIDE

VEHICLE HEADLAMP TEST – 12-PIN HARNESS – 3-RELAY SYSTEM ONLY




* Repair wire or replace harness for all open or shorted wires.

TROUBLESHOOTING GUIDE


PLOW HEADLAMP TEST – 12-PIN HARNESS – 3-RELAY SYSTEM ONLY

1. Verify correct harness and wire installation to headlamp relays, vehicle headlamps, and vehicle headlamp connectors.
2. All bulbs must be good.
3. Connect all harnesses at the front of the vehicle.
4. Turn vehicle headlamp switch ON. For vehicles with Daytime Running Lamps (DRLs), turn ignition ON. DRL equipped vehicles have a pink wire instead of a brown wire on relay terminal 86.
5. Verify power for both high and low beam and ground are present at the original vehicle headlamp connectors.
6. Refer to the Electrical Schematic – 12-Pin Harness, and the Headlamp Test Diagram – 12-Pin Harness. The specific wiring diagram for the vehicle can be found in the snowplow Installation Instructions, or the manual Electrical Schematics Guide.




TROUBLESHOOTING GUIDE

PLOW HEADLAMP TEST – 12-PIN HARNESS – 3-RELAY SYSTEM ONLY



TROUBLESHOOTING GUIDE

HEADLAMP TEST DIAGRAM – 12-PIN HARNESS – 3-RELAY SYSTEM ONLY (1998 AND OLDER VEHICLES)





Western Products
P.O. Box 245038
Milwaukee, WI 53224-9538
www.westernplows.com

 A DIVISION OF DOUGLAS DYNAMICS, LLC

Copyright © 2022 Douglas Dynamics, LLC. All rights reserved. This material may not be reproduced or copied, in whole or in part, in any printed, mechanical, electronic, film, or other distribution and storage media, without the written consent of Western Products. Authorization to photocopy items for internal or personal use by Western Products outlets or snowplow owner is granted.

Western Products reserves the right under its product improvement policy to change construction or design details and furnish equipment when so altered without reference to illustrations or specifications used. Western Products or the vehicle manufacturer may require or recommend optional equipment for snow removal. Do not exceed vehicle ratings with a snowplow. Western Products offers a limited warranty for all snowplows and accessories. See separately printed page for this important information. The following are registered (®) or unregistered (™) trademarks of Douglas Dynamics, LLC: FloStat®, PRO PLUS™, UltraMount®, WESTERN®.

Printed in U.S.A.