



Approved Mount Offering as of March 29, 2010

Dodge

Use: 29070-1 Module

Mount #	Part #	Vehicles	3 PORT Harness Kit(s)
989	67980	1994 - 2001 4 X 4 Ram 1500 1994 - 2002 4 x 4 Ram 2500 & 3500	29050 (HB1) OR 29050 & 29056-1 (HB5/HB1 - QUAD)
959	63760	2002 - 2005 4 X 4 Ram 1500	29050
969	63883-2	2003 - 2009 4 X 4 Ram 2500 & 3500 2006 - 2009 4 X 4 Ram 1500 Mega Cab	29050 OR 29049 (2006/07 H13) 29049
30999	30999	2006 - 2008 4 X 4 Ram 1500 Regular Cab	29049
3919	3919	2000 - 2003 4 X 4 Durango 2000 - 2004 4 X 4 Dakota	29050 29050
33929	33929	2005 - 2010 4 X 4 Dakota	29049
33939	33939	2008 - 2009 4 X 4 Ram 4500 & 5500 & Sterling 45/55	29049
33949	33949	2009 4 X 4 Ram 1500	29049 OR 29049 & 28027-2 (HB-3/11)
33884	33884	2010 4 X 4 Ram 2500 & 3500	29049 OR 29049 & 28027-2 (HB-3/11)

Ford

Use: 29070-1 Module

Mount #	Part #	Vehicles	3 PORT Harness Kit(s)
1229	67810	1997 - 2004 4 X 4 F-150, F-250LD	29050
1369	1369	1992 - 1996 4 X 4 F-150 and Bronco	29050
1379	1379	1992 - 1997 4 X 4 F-250, F-350, and F-Superduty	29050
3219	67982	1999 to 4 X 4 F-250SD, F-350, F-450, F-550 Early 2004 4 X 2 F-450, F-550	29050 OR 29051
1349	63710-1	1980 - 1991 4 X 4 F-150, F-250, F-350, Bronco 4 X 2 F-250, F-350	29050 OR 29051
3239	64500	2004 - 2008 4 X 4 F-150 "New Style" (min 8200 lb GVWR)	29049
3249	3249	Late 2004 4 X 4 F-250SD, F-350, F-450, F-550 4 X 2 F-450, F-550	29050 OR 29051
33259	33259	2005 - 2007 4 X 4 F-250SD, F-350, F-450, F-550 2005 - 2007 4 X 2 F-350, F-450, F-550	29049 (H13) OR 29051 (2B/2D/HB2)
31269	31269	2008 - 2010 4 x 4 F-250SD, F-350, F-450, F-550 2008 - 2010 4 X 2 F-450, F-550	29049 (H13) OR 29051 (2B/2D/HB2) use module 29760-1 for all 2008 Ford SD applications
68600	68600	2009 - 2010 4 x 4 F-150	29049
TBD	TBD	2011 4 x 4 Super Duty Series	TBD

Note: Due to 2011 model year changes, mount 31269 will not carryover.



Approved Mount Offering as of March 29, 2010

GM

Use: 29070-1 Module

Mount #	Part #	Vehicles			3 PORT Harness Kit(s)
1519	63900	1973 - 1987	4 X 4	1500, 2500, 3500	29050 & 26641-1 adapter (1A/2A)
		1973 - 1991	4 X 4	Suburban 2500	OR 29051 (2B/2D)
1589	67865	1988 - 1998	4 X 4	1500, 2500, 3500	29048 (HB3/HB4) OR 29051 (2B/2D)
		1992 - 1999	4 X 4	Suburban 1500, 2500	
3519	67960-1	1999 - 2007	4 X 4	1500 "Classic"	29048
		1999 - 2004	4 X 4	Tahoe/Yukon 1500	(99) 29048 OR 29051 (00-06) 29048
		2004 - 2006	4 X 4	Avalanche 1500	
31599	31599	2007 - 2010	4 X 4	GM 1500 All New (GMT900)	29400-2
3529	67981-2	1999 - 2006	4 X 4	1500HD, 2500, 3500	29048
		2001 - 2005	4 X 2	C3500 & C3600	29048
		2000 - 2006	4 X 4	Suburban/Yukon XL 2500	29048
		2002 - 2005	4 X 4	Avalanche 2500	29048
		2007	4 X 4	1500HD	29048
		2007 - 2010	4 X 4	2500HD, 3500 All New (GMT900)	} 29400-2
		2007 - 2010	4 X 2	C3500 All New (GMT900)	
		2007 - 2009	4 X 4	Suburban 2500 All New (GMT900)	
		2007 - 2009	4 X 4	Yukon XL 2500 All New (GMT900)	
3539	64110	2002 - 2009	4 X 2	4500 & 5500	29053
				Applications limited to 7,000 lbs FGAWR	
33559	33559	2005 - 2009	4 X 4	4500 & 5500	29053
TBD	TBD	2011	4 X 4	2500HD, 3500	TBD

Note: Due to 2011 model year changes, mount 67981-2 will not carryover.

Mitsubishi

Use: 29070-1 Module

Mount #	Part #	Vehicles			3 PORT Harness Kit(s)
33109	33109	2005 - 2008	4 X 4	FG	29050 & 28860-1 adapter

Toyota

Use: 29070-1 Module

Mount #	Part #	Vehicles			3 PORT Harness Kit(s)
31139	31139	2007 & 2010	4 X 4	Toyota Tundra	29400-2

Nissan

Use: 29070-1 Module

Mount #	Part #	Vehicles			3 PORT Harness Kit(s)
35066	35066	2004 - 2009	4 X 4	Nissan Titan	29048 & 28027-2 adapter