

1. Position the screen with the tabs facing the tailgate of the truck.
2. Place the screen into the hopper with the tabs entering first.

