



WESTERN PRODUCTS
7777 NORTH 73RD STREET
P.O. BOX 23045
MILWAUKEE, WISCONSIN 53223



A DIVISION OF DOUGLAS DYNAMICS, INC.

49248 SERVICE KIT

FOR 1990 FORD SUPER
CAB AND CHASSIS CAB
LIGHT TRUCKS
June 20, 1989

SUPPLEMENT INSTRUCTIONS
FOR
MODELS 1340, 1380 & 1390 FORD LIFT-MOUNT ASSEMBLIES

This supplement instruction applies to 1990 & Later Ford F150, F250 & F350 Super Cab and Chassis Cab vehicles produced after August 1989.

The vehicle frame horn end to which the snowplow Lift Frame attaches no longer has the top slot as illustrated in the diagram and described in Para. 2 of Installation Instruction Form No.'s 13303, 13315 & 13372.

Attach Lift Frame to the bottom slot of vehicle frame per Para. 2 of instructions. Clamp Lift Frame to vehicle frame at top horizontal slot with Spacers and Clamp Pads furnished in this kit, and 5/8" X 2" bolts, flat washers and locknuts furnished in Lift-Mount box. NOTE: Eight (8) spacers are furnished. Use a combination of spacers equal to the frame thickness to assure proper clamping of lift to vehicle frame. (See illustration below.)

Complete the installation per instructions in Lift-Mount box.

