



WESTERN PRODUCTS  
P.O. BOX 245038  
MILWAUKEE, WI 53224-9538



## 66760K MVP® SNOWPLOW TO STRAIGHT BLADE ADAPTER KIT

### INSTALLATION INSTRUCTIONS

A DIVISION OF DOUGLAS DYNAMICS, L.L.C.

## INSTALLATION INSTRUCTIONS

The adapter kit provides the capability to use a straight blade snowplow on a vehicle equipped with the MVP snowplow harness system. The adapter cable must be used with either a solenoid control or a CabCommand straight blade control. To use the adapter kit, follow Steps 1–6.

### WARNING

The driver shall keep bystanders clear of the blade when it is being raised, lowered, or angled. Do not stand between the vehicle and the blade, or within 8 feet of a moving blade. A moving or falling blade could cause personal injury.

1. Remove the V-plow from the vehicle according to the *MVP Snowplow Owners Manual*.
2. Remove the V-plow CabCommand control from the system by twisting the connector ring counterclockwise at the end of the coiled cord and pulling it out.
3. To install the adapter cable, plug the 14-pin connector end into the 14-pin connector on the dashboard.
4. Install the straight blade CabCommand control or the solenoid control by mating the 6-pin connector ends.

5. Install the straight blade snowplow according to the *Straight Blade Owners Manual*.
6. See the *Straight Blade Owners Manual* for operation instructions for the straight blade snowplow.

**NOTE:** The 2-pin straight blade snowplow battery cable connector will mate correctly with the 3-pin V-plow vehicle connector. The small pin is not required for straight blade use.

**NOTE:** Operating a V-plow with a solenoid control will cause the motor to run when the control is plugged in. The snowplow will not move, and no damage will occur.

**NOTE:** Operating a V-plow with a straight blade CabCommand control will cause the motor to run and the right wing to retract when the UP, LEFT, or RIGHT functions are activated. No damage will occur.

**NOTE:** Operating a straight blade snowplow with the V-plow control will cause the motor to run when any function except DOWN, is activated. The snowplow will not move, and no damage will occur.



Western Products reserves the right under its Product Improvement Policy to change construction or design details and furnish equipment when so altered without reference to illustrations or specifications used herein. Western Products and the vehicle manufacturer may require and/or recommend optional equipment for snow removal. Western Products offers a limited warranty on the snowplows and accessories. See separately printed page for this important information. The following are registered (®) trademarks of Douglas Dynamics, L.L.C.: MVP® and WESTERN®.