



WESTERN PRODUCTS
7777 NORTH 73RD STREET
P.O. BOX 23045
MILWAUKEE, WISCONSIN 53223




A DIVISION OF DOUGLAS DYNAMICS, INC.

Box No. 61070
Model No. 1570
Chevrolet & GMC
C30/3500 2WD
1988 and Later
April 9, 1990

PARTS DIAGRAM & LIST

Abbreviations	
BP	Black Phosphate
BPO	Black Phosphate & Oil
BZP	Black Zinc Plate
CS	Capscrew
CU	Curb Side
DR	Driver Side
G	Grade
HD	Heavy Duty
HX	Hex
LK	Lock
MS	Machine Screw
NAR	Narrow
NYIS	Nylon Insert
PT	Prevailing Torque
RD	Round
STD	Standard
TRTS	Thread Rolling Tapping Screw
TY	Type
ZP	Zinc Plated



NOTE: Colored fasteners are Metric

MINIMUM VEHICLE RECOMMENDATIONS

Aux. Light Kit
HD Alternator
HD Battery
HD Suspension
P235/75R15 Tires

REAR BALLAST - 300 to 500
lbs. when blade is attached.
WEIGHTS MUST BE SECURED.

ITEM	PART NO.	QUAN.	DESCRIPTION
------	----------	-------	-------------

1	61253	1	LIFT FRAME 1570
2	60801	1	THRUST BRACKET DR
3	60802	1	THRUST BRACKET CU
4	60817	1	THRUST ANGLE CU
5	60818	1	THRUST ANGLE DR
6	60816	2	REINFORCING BAR
7	60821	1	CLAMP PLATE
8	60927	2	LOWER BRACE ARM
9	60928	2	UPPER BRACE ARM
10	60929	1	BUMPER BRACKET DR
11	60930	1	BUMPER BRACKET CU
12	60917	1	PLASTIC SHIELD DR
13	60918	1	PLASTIC SHIELD CU
14	60934	2	STAND OFF-MIDLAND PLASTICS #03
15	61073	1	SPACER
16	93164	4	1/4-20X1 HX TRTS TY TT BPO
17	90067	4	7/16-14X1-1/2 HX CS G5 ZP
18	90099	4	1/2-13X1-1/4 HX CS G5 ZP

ITEM	PART NO.	QTY.	DESCRIPTION
------	----------	------	-------------


19	90100	8	1/2-13X1-1/2 HX CS G5 ZP
20	90127	2	5/8-11X1-1/2 HX CS G5 ZP
21	90128	1	5/8-11X1-3/4 HX CS G5 ZP
22	91100	4	1/4 PLAIN WASHER TY A STD BP
23	91104	8	7/16 PLAIN WASHER TY A STD ZP
24	91105	2	1/2 PLAIN WASHER TY A STD ZP
25	91214	1	WASHER - SPECIAL
26	91334	4	7/16-14 PT HX LK NUT NYIS ZP
27	91335	12	1/2-13 PT HX LK NUT NYIS ZP
28	91337	3	5/8-11 PT HX LK NUT NYIS ZP
29	95184	4	M12X1.75 PT HX LK NUT NYIS
30	93028K	2	HITCH PIN 1" X 3-1/2"
31	91965K	2	HAIRPIN COTTER 5/32

PARTS NOT SHOWN

55930	1	BATTERY CABLE ADAPTER
90308	2	#10-24X3/4 RD MS BZP
91098	2	#10 PLAIN WASHER TY B NAR ZP
91401	2	#10-24 HX NUT ZP

Box No. 61070
 Model No. 1570
 Chevrolet & GMC
 C30/3500 2WD
 1988 and Later
 April 9, 1990

INSTALLATION INSTRUCTIONS



NOTE

LIFT FRAME SIDE PLATE ATTACHMENT
DRIVER SIDE — INSIDE OF FRAME
CURB SIDE — TO INBOARD SURFACE
OF FRAME



Recommended Fastener Torque Chart (Ft.-Lbs.)				
Size	SAE Grade 2	SAE Grade 5	SAE Grade 8	
1/4-20	6	9	13	
5/16-18	11	18	28	
3/8-16	19	31	48	
3/8-24	24	48	68	
7/16-14	30	50	75	
1/2-13	45	75	115	
9/16-12	66	110	165	
5/8-11	93	150	225	
3/4-10	150	250	370	
7/8-9	202	378	591	
1-8	300	583	893	

Metric Grade 8.8 (Ft.-Lbs.)			
Size	Torque	Size	Torque
M 6	7	M 12	60
M 8	17	M 14	95
M 10	35	M 16	155

These torque values apply to lift-frame fasteners except those noted in the instruction.

NOTE: DIRECT HYDRA-TURN®
HOSES AND FITTINGS AWAY FROM
STOPS AND PINCH POINTS.

AS VIEWED FROM CURB SIDE



17028

IMPORTANT: Read instructions before assembling. Bolts should be finger tight until the installation is completed. Preventive maintenance can prevent accidents. Use standard methods and practices when attaching snowplow including wearing safety glasses during drilling.

1. Remove bumper with brackets. (NOTE: Loosen diagonal braces to clear body mounts.) Remove brackets and diagonal braces from bumper. Retain driver side bumper bracket and shim and replace whenever Lift Frame is removed from vehicle.
2. Install Lift Frame to frame end (See Note in diagram above). Driver Side - secure with 3 existing 14mm bumper bracket bolts. Curb side - insert 5/8" x 1-3/4" bolt thru hole in Lift Frame side plate. Place 1-1/8" O.D. flat washer on the bolt and into frame hole. Place Clamp Plate (holes to match lift side plate pattern) inside frame rail and onto the 5/8" bolt, tightening locknut enough to keep washer in frame hole.
3. Attach Thrust Brackets (single hole leg inboard and trim toward rear) to bottom of frame rails with Reinforcing Bar inside. Secure with 1/2" x 1-1/2" bolts and locknuts.
4. Attach Thrust Angles (trimmed end inboard of Thrust Bracket) to bottom angle of Lift Frame. Secure with 1/2" x 1-1/2" bolts and locknuts.

5. Position Lift Frame to obtain 3/8" to 3/4" clearance to grille. On each side, scribe Thrust Angle hole location thru hole in Thrust Bracket. Remove Thrust Angles and accurately drill 5/8" holes at scribe marks. Reattach to Lift Frame and fasten to Thrust Brackets with 5/8" x 1-1/2" bolts and locknuts.
6. Curb Side - using one hole in Lift Frame side plate as a template, drill 1/2" hole thru vehicle frame rotating Clamp Plate to proximity of drill breakthrough. Secure with 1/2" x 1-1/2" bolt and locknut. Drill second hole and secure.

TIGHTEN ALL BOLTS TO CORRESPONDING TORQUE CHART VALUES.

7. Replace existing curb side bumper bracket and serrated shim and secure with existing fasteners.
8. Assemble furnished Bumper Brackets to outside of Lift Frame side plates (Spacer to driver side) using 7/16" x 1-1/2" bolts, flat washers to slots and locknuts. (NOTE: Top legs of brackets to be parallel to Lift Frame center angle.)
9. Assemble straight Upper and offset Lower Brace Arms to ends of diagonal braces with existing fasteners. Replace diagonal braces to body mounts and secure with existing fasteners.
10. Attach bumper to Bumper Brackets with existing 12mm bolts and furnished 7/16" flat washers to bracket slots and 12mm locknuts. Fasten brace arms to bumper with 1/2" x 1-1/4" bolts, flat washers to slots and locknuts. Position bumper and tighten all fasteners.
11. Install Plastic Shields between grille and bumper, textured side up. Drill 7/32" hole into curb side bumper bracket thru shield slots. Place plastic Stand Offs to outboard Upper Brace Arms. Fasten with 1/4" x 1" thread forming screws and black flat washers.

NOTE: Colored fasteners furnished in this box are Metric.

HYDRAULICS: Mount the Hydraulic System using the instructions furnished in the Hydraulic Carton and on the envelope furnished in bolt bag in this carton. **ISARMATIC® MOTOR GROUND CABLE MUST BE GROUNDED TO A CAPSCREW ON THE ENGINE.**

LIGHT KIT ASSEMBLY - Do NOT change flasher. FOR DUAL TYPE 2B HEADLAMPS - Use Box No. 60740 Headlamp Kit - 4 Wire and Box No. 60745 Harness Bracket Kit - 2B/2D. FOR 1988 & 1989 QUAD TYPE LF & UF HEADLAMPS - Use Box No. 60740 Headlamp Kit - 4 Wire with Box No. 60780 Harness Bracket Kit - LF & UF. FOR 1990 & LATER QUAD COMPOSITE TYPE HB3/HB4 HEADLAMPS - Use Box No. 60740 Headlamp Kit - 4 Wire and Box No 61315 Harness Bracket Kit - HB3/HB4.

IIIa CONTROL AND DASH BRACKET INSTALLATION INSTRUCTIONS, SEE PAGE 4

SPECIAL INSTRUCTIONS	
-----------------------------	--

Chevrolet and GMC Light Trucks	
-----------------------------------	--

ENGINE OVERHEATING


In the event vehicle engine overheating occurs while traveling with the blade attached, the CLUTCH FAN ASSEMBLY should be checked by a General Motors Dealer's Service Department per Chevrolet Service Bulletin 6B.

HAZARD WARNING CIRCUIT

Snowplow auxiliary Park/Turn Hazard Lights can overload the vehicle electrical circuit when Hazard Lights flash for extended periods or when foot brake is activated with Hazard Lights flashing.

GM recommends that a light harness and relays be installed for auxiliary snowplow lighting. See your GM dealer for service bulletin # 90-8A-20. Western also offers a Directional Harness Kit, see Service Bulletin SP 619.

INSTALLATION INSTRUCTIONS
FOR — IIIa CONTROL
TO VEHICLE INSTRUMENT PANEL
CHEVROLET & GMC



1. Remove the center (air vent) section of the dash, located between the radio/climate control and the glove compartment. Pry out at the bottom, then press in at the top while pulling down and out at the bottom. Disconnect any electrical equipment attached to the panel.
2. Secure the dash bracket to the IIIa Control using four (4) No. 8 x 5/8" hex head screws.
3. Locate IIIa Control to the right of the ash tray, and up to the bevel on the flat recessed surface. The bracket should fit fairly flat against the surface of the dash. Verify that IIIa Control lever will clear vehicle components in all positions and for adequate drill clearance (look into opening, to locate ribs) before drilling holes.
4. Mark this location.
5. Remove the bracket from the IIIa Control. Place the bracket in the selected location and mark all four (4) holes.
6. Drill 7/32" holes in the dash for the lower two holes, and 1/8" for the upper two holes, to align to the holes in the bracket. Secure using No. 10 x 3/4" machine screws, flat washers, and nuts (furnished in this carton) in the lower holes, and No. 10 x 1" sheet metal screws and lock washers (furnished in hydraulics carton) in the upper holes.
7. Place IIIa Control into bracket and fasten in desired position.
8. Replace the dash section.


17029

INSTALLATION INSTRUCTIONS
FOR 59700 BLADE GUIDE ASSEMBLY

Insert pointed end of clamp into coil of Blade Guide Rod. Attach a Blade Guide Rod to each outer rib using 5/16" x 1" capscrews and locknuts as shown in diagram.

PARTS LIST
59700 — BLADE GUIDE ASSEMBLY

Item	Part No.	Quan.	Description
1	59697	2	BLADE GUIDE ROD, S-HOOK & FLAG
2	59694K	1	BLADE GUIDE FLAG
3	59696	1	S-HOOK
4	59691	1	BLADE GUIDE ROD
5	59946	2	CLAMP
6	90020	4	5/16-18X1 HX CS G2 ZP
7	91332	4	5/16-18 PT HX LK NUT NYIS ZP



13009-8908

The following are registered® and unregistered™ Trade Marks of Douglas Dynamics, Inc.
 WESTERN® ISARMATIC® Hydra-Turn® Roll-Action™ PRO-GUARD™

Western reserves the right under its Product Improvement Policy to change construction details and furnish equipment when so altered without reference to illustrations or specifications used herein.